

RACK MOUNTING - WIDE ADJUST OUTPUT POWER SUPPLIES with Fixed Current Limiting

INSTALLATION AND OPERATION

These power supplies are constructed in the form of assemblies that are front mountable in standard 19" wide RETMA cabinet racks. If possible, mount in the rack spaced away from other heat dissipating or air blocking assemblies, by using blank front panels above and below each power supply. This will result in cooler running operation, which in turn will maximize stability and reliability.

Make all connections before applying AC input power.

THE SENSING TERMINALS <u>MUST</u> BE CONNECTED to the output terminals, either at the barrier strip on the power supply or at the load. Failure to have the sense terminals connected will affect the output voltage (usually causing it to be higher than the rating of the supply, and unadjustable), and may result in permanent damage to both the power supply and its load. If voltage drops in the output voltage leads (which degrade regulation) are not objectionable, local sensing can be used; leave in place the jumpers provided with the power supply on the barrier strip (connecting the +SENS to the +OUT terminal and the -SENS to the -OUT terminal). However, if the best possible regulation at the load is required, then remove the jumpers and use two additional leads to connect the sense terminals to the output leads at the load, as shown in the schematic. This configuration permits the power supply to sense and compensate the voltage actually across the load. Note that remote sensing is capable of compensating only limited wiring drops. The voltage across the load, plus the voltage drops through the wiring, must be within the output voltage range of the supply for the voltage at the load to remain within the load regulation specification.

If there is any possibility of voltage from another source (another power supply, a battery, transients, etc) being applied to the power supply's output terminals, protect the power supply by using a diode in series with one of the output leads.


Do not attempt to directly parallel the outputs of two power supplies. This would result in current flowing from the higher-set output into the lower-set output, and probable damage to both circuits. Outputs may be connected in series to obtain a higher voltage provided that a reverse-biased diode, having PIV and current ratings exceeding the combined output, is used across each output; however, keep in mind that the output current to be drawn cannot exceed the output current rating of the lowest rated supply used.

If the AC input power contains large voltage spikes ('noise') induced by the switching of high currents, inductive loads, electro-

mechanical components, etc., the input power leads to the supply should include some means of transient suppression. Otherwise, a portion of the noise may be coupled through the supply to the load. Also, the supply could be damaged. The means of suppression that is easiest to install is a 1 mfd capacitor or a metal oxide surge suppressor (MOV) across the AC input terminals of the supply. In extremely severe cases, the use of RF chokes in series with each side of the line may also be required.

Current limiting and short circuit protection: all models have a rolloff characteristic with automatic recovery.

protection The overvoltage circuit of power supplies equipped with this option will trip whenever the output voltage rises to the trip voltage (even if only instantaneously, as can occur if a load transient feeds back into the power supply), and will remain latched until the output voltage is interrupted. It can be reset without changing the control settings simply by switching the power supply off momentarily.



THE DOTTED LINE CONNECTION IS REQUIRED, unless remote voltage adjustment is used. A potentiometer OR switched resistors in the negative sense lead may be used to remotely program (adjust) the output voltage:

If using a potentiometer (as shown above), the


built-in adjustments must be turned fully CCW.
The remote pot(s) should have these values:
For 0-6v, 0-15v, 0-30v models;

use a 5K pot (0.5w) for V COARSE adj, use a 500 ohm pot (0.5w) for V FINE adj. For 0-50v, 0-100v models;


use a 50K pot (0.5w) for V COARSE adj, use a 5K pot (0.5w) for V FINE adj.


If using switched resistors, the built-in output voltage controls must be turned counterclockwise at least to a point where the minimum desired voltage can be obtained with the minimum external resistance used. The switch should be of the make-beforebreak type (damage to the power supply, and to the load, may result from the output voltage surges caused by open-circuiting the sensing circuit while the supply is in operation). Use these values:

P.S. Output Voltage Range	Ohms/Volt
0 to 6v	820
0 to 15v	330
0 to 30v	160
0 to 50v	1000
0 to 100v	500



Rear Panel Connections:





Case Sizes 3P11 and 5P12

Case Sizes 3P17 and 5P17





131 Loomis Street, Easton, PA 18045 · Phone: (610) 258-5441 · FAX: (610) 258-2842